



UBA LEVEL GUY:

1. Using a hacksaw or angle grinder (eye protection to be worn), cut 20mm off one table leg.
2. File away all sharp edges.
3. Place the Level Guy against the shortened leg. The adjustable foot must move in and out of the inside of the leg, not outside of it. The rivnut must be completely hidden inside the leg.
4. Mark the two holes and drill using a 4.8mm drill bit. (Eye protection to be worn)
5. Pop rivet the Level Guy into place using the 2 x 4.8x12mm pop rivets supplied.