



Fitting Instructions:

UBA BONNET SPOTLIGHT BRACKET:

UBA/BSB:

There should be two brackets, four J-bolts and two pieces of rubber edging.

Open the vehicles bonnet and secure.

Identify a large hole on the underside of the bonnet close to the windscreen edge, one left and one right. This is the hole where the J-bolts will hook into.

Now place the rubber edging onto the bonnet closest to the windscreen opposite these holes with the fat side facing upwards. Ensure that the hole is centered to the rubber.

Place the bracket over the rubber and secure in place with the J-bolts (2 per bracket). Tighten each nut little by little to prevent the bracket from shifting too much to one side.

Once tightened, the spotlights may be installed.

NB: These brackets are designed for small, light spotlights.