



UBA SAND TRACK MOUNT – BOLT-ON:

1. These brackets can be used on any flat surface to mount sand tracks, spade, axe and hi-lift jack.
2. Position the two UBA SAND TRACK MOUNT brackets according to the measurement required to fit the sand tracks.
3. Mark the four holes and drill using an 8.5mm bit. (Eye protection to be worn)
4. Seal the four holes using silicone or similar product and bolt the UBA SAND TRACK MOUNT brackets in place using the four M8 x 20mm bolts, washers and nyloc nuts supplied.
5. Should an axe, spade or hi-lift jack be installed, ensure the distance between the brackets are correct according to the length of the accessory being fitted.