



UBA SAND TRACK MOUNT LC70 CLAMP-ON FITTING INSTRUCTIONS:

1. Loosely assemble the brackets and cross members with the hardware supplied.
4 x M8x60 set screws
4 x M8 nyloc nuts
8 x M8 washers
2. Apply the supplied clear film to the edge of the bonnet in the position that you prefer the UBA Sand Track Mount to rest. 250mm must be on the top surface and the remainder of the film must be shaped around the outer and lower edge.
3. Place the assembly into position ensuring that the clamps are seated correctly around each end.
4. Feed the supplied ratchet strap through the two opposing slots in each clamp and tighten.
5. Once the two clamps have been pulled toward each other and are secure, tighten the four M8 bolts, washers and nuts.
6. The ratchet strap can now be removed or left in place.
7. Place the two sand tracks onto the mounts with the four M8 bolts passing through the original round holes. Using the red eye bolts and large fender washers, tighten and secure.