



UBA REAR WHEEL TABLE FITTING INSTRUCTIONS:

1. Loosely fit the UBA REAR WHEEL TABLE to the rear wheel with the supplied hardware through the appropriate holes, do not tighten yet.
2. Feed the supplied ratchet strap through the elongated slots in the four feet and tighten securely.
3. Fasten the hardware ensuring the correct holes have been selected.